For Your Convenience: This Perkins File Is Shared By Diesel Parts Direct



YOUR ONE STOP SUPERSTORE FOR DIESEL ENGINE PARTS

SHOP NOW



To be eligible for a full credit, your Perkins core must meet the following:

- 1. Be the same build configuration as supplied, with all components fitted
- 2. Must be returned without prior disassembly
- 3. Must bar over 360 degrees without abnormal noise or resistance
- 4. Must not show any visible holes, cracks or damage to castings or components
- 5. Must be properly attached to the skid and drained of all fluids

Credit and Billing Details

- 1. If the core received does not meet the requirements listed above, there will be an additional charge of up to half of the eligible credit value
- 2. Any damaged or missing components will be charged back at Dealer List pricing
- 3. We will not issue Customer Credit until the Perkins Reman Facility has inspected the unit and issued a credit

Additional Notes

Your returned engine core should be well wrapped so water or trash does not get into the engine core. Should water or trash enter the core, and as a result, rust or debris keeps the crankshaft from turning smoothly for 360 degrees, the Reman Center will consider the core as not meeting the standards listed above.